IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING APPLIANCE. KEEP AWAY FROM WATER.

DANGER

When the unit is used in a bathroom, remove batteries before use since the proximity of water presents a hazard even when the unit is switched off.

WARNING — TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

- 1. Read all instructions before using the appliance.
- 2. To protect against electrical hazards, do not use while bathing or in the shower.
- This appliance should not be used by adults or children whose lack of experience, product knowledge or disability might cause a hazard, unless they have been correctly instructed and are adequately supervised.

Children should always be supervised to ensure that they do not play with this product.

4. Do not operate this appliance if the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to nearest service facility for examination, electrical or mechanical adjustment, or repair. No repairs should be attempted by the consumer.

5. Use appliance only for intended use as described

in this instruction book. The use of attachments not recommended or sold by Conair may cause hazards.

- 6. Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
- 8. Do not use on a soft surface such as a bed, where openings may be blocked.
- 9. Turn switch to Off position before storage.
- 10. Do not place or store appliance where it can fall or be pulled into a tub or sink.

11. Do not place in or drop into water or other liquids. **DO NOT REACH INTO THE WATER.**

INSTRUCTIONS FOR USING

BATTERIES


- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace old batteries of a set at the same time.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
- Clean the battery compartment by blowing away any debris and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove batteries promptly.

FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE THE MIRROR; REFLECTED SUNLIGHT CAN CAUSE FIRE.

- 1. Your LED lighted makeup mirror has a 21.5 x 16.5cm oval design head with a 7x/1x magnification.
- 2. This unit operates on 3 AA batteries (not included, see illustration).
- 3. After use, always turn switch to the Off position.
- 4. The beauty and design of this mirror will complement any environment. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see STORAGE for detailed information.
- 5. This mirror has an on/off switch on the base.



3 AA batteries needed

(Fig. 1)

TO INSTALL BATTERIES (not included)

- 1. Remove battery cover after loosening the screw.
- 2. Install 3 AA new batteries as indicated on battery compartment (Fig. 1).
- 3. Replace battery cover by snapping it into place and tightening the screw.

BATTERY DISPOSAL

Batteries contain various materials that must be recycled and disposed of properly. Do not dispose in the municipal waste system.

SPECIAL FEATURE

This lighted makeup mirror uses Lifetime Energy Saving LED bulbs. Replacement bulbs are not required.

STORAGE

Turn switch to off position. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged.

MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed.

If cleaning becomes necessary, turn off the appliance, allow to cool and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry. If any abnormal condition occurs, turn off the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

LIMITED ONE YEAR WARRANTY

This product is subject to the express warranty given on the warranty card included with the product, as may be amended by reference to and in accordance with the terms of the warranty cards displayed on Conair website www.conairaustralia.com.au

To make a warranty claim you must retain your proof of purchase. Further details can be found at www.conairaustralia.com.au and click on 'customer service'.





CONA!P®

©2017 Conair Australia Pty. Ltd. Suite 101, 18 Rodborough Rd Frenchs Forest NSW,2086 Customer Service Hotline Australia: 1800 650 263 New Zealand: 0800 266 247 E-mail: aus_info@conair.com www.conairaustralia.com.au

IB-



Battery operated (3 AA not included) For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Model CBE51LBRA